



No-Step Entry

The most important element of Adaptive Laneway Living begins with a no-step entry to allow for a smooth transition from outdoors to indoors.

Designing & building your no-step entry will alleviate any unsightly ramps and/or mechanical lifts not in keeping with your laneway suite's design should you (or your family/tenants) experience any mobility changes.

Required Elements

1. An accessible path of travel

- From the street, the laneway and/or private parking area to at least one suite entry door
- Minimum 48" wide (1200 mm) smooth pathway to suite entry
- Slope of pathway not to exceed 1/12 slope

[See Video](#)[Spec Sheet](#)